

# ONCO-SYSTEM RELIABLE PROTECTION FOR VITAL CYTOSTATICS



# EFFECTIVE PARTNER FOR ONCOLOGY:

# ONCO-SYSTEM

Pharmacies, manufacturers of cytostatic drugs, and laboratories carry a lot of responsibility. Particularly in oncology, as cytostatic drugs and parenteral preparations are individually mixed, and these life-saving medications are especially temperature sensitive.

### RELIABLY PROTECTED

The Onco-System is the optimal solution for safe transport of cytostatic drugs and parenteral preparations.

Thanks to the tailored segment solution for pharmacies and manufacturers of medications, life-saving, temperature sensitive medications reach patients at the right temperature. This is made possible by the proven phase change material (PCM) technology of the accumulators made of robust, hard plastic, whose melting range is

precisely tailored to the required temperature range – in both winter and summer. The box size is also designed for IV bags, allowing them to lie flat, which prevents damage during transport such as kinks in the bag or infusion instruments.

The Onco-System is the ideal solution for more than just the optimal temperature. The boxes for temperature-controlled transport close up tightly and feature additional sealing with a lining and closure seal, thus ensuring reliable leakage protection at all times. The overall system solution is made of durable EPP and can thus be used repeatedly, without losing its clean appearance. Thanks to the smooth material surface and the removeable lining, all Onco-System components can be effectively and easily cleaned.

	15 l	27 l	15 l	27 l
External dimensions in mm	646 x 415 x 290	646 x 415 x 377	646 x 415 x 290	646 x 415 x 377
Loading capacity in mm	490 x 290 x 105	500 x 300 x 180	490 x 290 x 105	500 x 300 x 180
Payload in l	15	27	15	27
Duration in hours	25	17	33	33
Temperature range	2-8°C	2-8°C	15-25°C	15-25 °C



### Simple to Tell Apart:

Cancer patient treatment often has to be carried out quickly and mistakes need to be prevented, which is why the Onco-System is also especially easy to use. Colored specks specify the application and contents of the boxes, so that, for instance, boxes for cytostatic drugs can be identified at a glance.



### THE BENEFITS OF THE ONCO-SYSTEM

- ▶ JUST THE RIGHT TEMPERATURE: OPTIMAL TEMPERATURE RANGE THANKS TO PCM ACCUMULATORS IN BOTH WINTER
  AND SUMMER FOR THE TEMPERATURE RANGES 2 TO 8°C AND 15 TO 25°C
- SAFE: THE BOX CONCEPT AND SIZE ENABLE SAFE TRANSPORT
- LEAKPROOF: BOXES CLOSE UP TIGHTLY AND FEATURE A LINING AND ADDITIONAL SEALING
- EFFICIENT: THANKS TO THE LINING, MEDICINES CAN BE PREPARED IN ADVANCE
- ROBUST: EPP BOXES CAN BE USED REPEATEDLY
- ► CLEAN: THE MATERIAL CAN BE EFFECTIVELY CLEANED
- STRAIGHTFORWARD: COLORED MARKINGS REVEAL CONTENTS AND APPLICATION AT A GLANCE
- COST-EFFECTIVE: REPEATED USE REDUCES COSTS AND CONSERVES RESOURCES
- ▶ SIMPLE: ALL SYSTEM COMPONENTS CAN BE REORDERED INDIVIDUALLY BUT ALSO FIT TOGETHER



The system solution consists of very few, optimally coordinated components that can be used repeatedly and reordered individually. If the box needs to be replaced, the accumulators and closures can still be used.

PERFECT PROTECTIVE PACKAGING ONCO-SYSTEM

### STOROPACK - PERFECT PROTECTIVE PACKAGING

Wherever in the world you send your products, we want them to be well protected while in transit.

### **OPTIMUM PROTECTION WITH MEDICAL SOLUTIONS**

Our insulated boxes and prequalified system solutions protect your temperature-sensitive products and ensure the optimum temperature range. Whether as disposable or robust, reusable solutions, our Medical Boxes get your products to their required destination at the right temperature.

**More about Storopack Medical:** www.storopack.de/medical

## CONTACT US

# Storopack Deutschland GmbH + Co. KG

Untere Rietstrasse 30 72555 Metzingen Germany

Asia-Pacific +852 3421 2392 Europe +800 7867 6722 North America +1 800 827 7225 South America +55 11 5677 4699

info@storopack.com www.storopack.com

